

Determine Door Handing and Set Lock Case Direction



Change Latch Bolt Direction for TL4 Latch






RA/SE/SH/GT/GS Tubular Latch GT/GS/GR/SR Privacy Bolt Installation Instructions

Tubular Latch Privacy Bolt

PM-ISTLPB-4438 V20250125

RA/SE/SH/GT/GS Rose with Tubular Latch Parts List:



Items	No.	Parts Description	Function				
			Privacy	Passage	Full Dummy	Half Dummy	Half Passage
Leverset Parts	1	Rose Inside w/Lever (Section A)	1 EA	1 EA	1 EA	1 EA	1 EA
	2	Rose Outside w/Lever (Section B)	1 EA	1EA	1 EA	-	-
	3	Outside Rose Cover	1 EA	1 EA	1 EA	-	-
	4	Inside Rose Cover	1 EA	1 EA	1 EA	1 EA	1 EA
	5	M4 x 40mm Bolt Sleeves	2 EA	2 EA	-	-	2 EA
	6	8 x 1-3/4" (45mm) Spring Spindle	2 EA	2 EA	-	-	1 EA
	-	Dummy Spindle for RA/SE	-	-	2 EA	1 EA	-
	-	#6 x 1" Wood Screws for RA/SE	-	-	6 EA	3 EA	-
	7	Privacy Pin	1 EA	-	-	-	-
	8	Set Screw	2 EA	2 EA	2 EA	1 EA	1 EA
	9	M4 x 1-3/8" (35mm) Machine Screw	2 EA	2 EA	-	-	2 EA
	-	#8 x 1" Wood Screws	-	-	8 EA	4 EA	-
Locks	10	Tubular Latch	1 EA	1 EA	-	-	1 EA
	11	Tubular Latch Faceplate	1 EA	1 EA	-	-	1 EA
	12	8# Screws for Tubular Latch Faceplate	2 EA	2 EA	-	-	2 EA
	13	8# Screws for Tubular Latch Striking Plate	2 EA	2 EA	-	-	2 EA
	14	Tubular Latch Striking Plate	1 EA	1 EA	-	-	1 EA
	15	Tubular Latch Dust Box	1 EA	1 EA	-	-	1 EA
Others	-	Door Prep Template	1 EA	1 EA	-	-	1 EA
	-	Installation Instruction	1 EA	1 EA	1 EA	1 EA	1 EA


RA/SE/GT/GS/SH Rose with Tubular Latch Installation Instructions:

For Passage/Privacy Function: L461/L462/L471/L472

1. Install tubular latch with (2) #8 Screws.


A Note: For privacy, privacy pin hub with thread must face inside of door (A-A)

- 2. Install outside lever with (2) M4 x 40mm bolt sleeves.
- 3. Install inside lever with (2) M4 x 35mm machine screws. Tighten set screw using Allen key. Note: For non-removable rose designs, use M4 x 35mm hexagon with Allen key (B-B).
- A Note: Ensure levers on both sides are horizontally level before tightening machine screws.
- Mount inside and outside rose cover (snap-on).
- 5. For privacy function, insert privacy pin into latch privacy pin hub (A-A).





106, 214, 251, 344, 379




- 1. GT/GS Outside Cover with or without Indicator Window
- 2. 2x Bolt Sleeves
- 3. GT/GS Outside Privacy Release Rose
- 4. GT/GS Inside Less Cover
- 5. 2x M4 Machine Screws
- 6. GT/GS Privacy Escutcheon
- 7. Thumbturn Washer
- 8. GT/GS Thumbturn
- 9. Set Screw for Thumbturn
- 10. Allen Key
- 11. Tubular Privacy Bolt
- 12. Faceplate for Privacy Bolt
- 13. Screws for Face Plate (2x #8 Screws)
- 14. Screws for Striking Plate (2x #8 Screws)
- 15. Privacy Bolt Striking Plate 16. Privacy Bolt Dust Box

Installation Steps


1. Install tubular deadbolt latch with (2) #8 Screws. Note: Please ensure the latch tongue is inside latch casing. For Dummy Function: DL / DR

- 1. For RA/SE, mount dummy spindle with (3) #6 wood screws. GT/GS does not need dummy spindle.
- 2. Install lever with (4) #8 wood screws.
- A Note: Ensure lever is horizontally level before tightening wood screws. 3. Mount rose cover.
- 4. Tighten set screw using Allen key.
- GT/GS does not need set screw.




For Half Passage Function: L465 / L475

- 1. Install tubular latch with (2) #8 Screws.
- 2. Install outside lever with (2) M4 x 40mm bolt sleeves.
- 3. Mount inside sub rose with (2) M4 x 35mm machine screws. Tighten set screw using Allen key.
- A Note: For non-removable rose designs, use M4 x 35mm hexagon with Allen key (B-B).
- A Note: Ensure the lever is horizontally level before tightening machine screws.
- 4. Mount inside and outside rose cover.








Parts List

- 1. GR/SR Outside Cover
- 2.8x #6 Wood Screws
- 3. GR/SR Outside Privacy Release Rose
- 4. GR/SR Inside Less Cover
- 5. GR/SR Privacy Escutcheon
- 6. Thumbturn Washer
- 7. GR/SR Thumbturn
- 8. Set Screw for Thumbturn
- 9. Allen Key
- 10. Tubular Privacy Bolt 11. Faceplate for Privacy Bolt
- 12. Screws for Face Plate
- 13. Screws for Striking Plate
- 14. Privacy Bolt Striking Plate
- 15. Privacy Bolt Dust Box

Installation Steps

- 1. Install tubular deadbolt latch with (2) #8 Screws.
- Note: Ensure the latch tongue is inside latch casing.

- 2. Mount privacy release rose with (2) bolt sleeves.
- 3. Mount privacy thumbturn rose with (2) M4 Machine Screws.
- 4. Mount privacy release rose cover.
- 5. Mount thumbturn rose cover and clear washer.
- 6. Mount thumbturn. Tighten set screw inside thumbturn using Allen key.



- 2. Mount privacy release rose with (4) #6 screws. 3. Mount privacy thumbturn rose with (4) #6 screws. 4. Mount privacy release rose cover.
- 5. Mount thumbturn rose cover and clear washer.

6. Mount thumbturn. Tighten set screw inside thumbturn using Allen key.

